[Retain for future reference.]

Adjustable Height Work Platforms


The platform that you have received on this order has adjustable legs which allows the user to adjust the height of the platform (see chart below).

Never work on a platform which is not level or on one which does not have all four legs in contact with the floor.

After the proper height is selected and the legs have been adjusted to make contact with the floor; the **lock nut** must be securely fastened against the **leg bottom plate.**

MODEL	LENGTH	WIDTH	ADJ. HEIGHT	MAXIMUM HEIGHT
AHW-L-2424	24"	24"	5" - 8"	8"
AHW-L-2436	24"	36"	5" - 8"	8"
AHW-L-2460	24"	60"	5" - 8"	8"
AHW-H-2424	24"	24"	9" - 14"	14"
AHW-H-2436	24"	36"	9" - 14"	14"
AHW-H-2460	24"	60"	9" - 14"	14"

ADJUSTABLE HEIGHT WORK PLATFORM ASSEMBLY



Steps For Assembly

- 1. Snug the lock nut against the leg bottom plate finger tight.
- 2. Using a wrench, secure the **lock nut** against the **leg bottom plate** by making a 1/8th turn of the **lock nut** or until **lock nut** is tight.
- 3. Understand and follow all usage guidelines and heed all cautions and warnings.

AWARNING

Never exceed the maximum height of the platform. Doing so may contribute to leg failure and the possibility of injury.



EGA PRODUCTS, INC. Manufacturers of material handling and storage equipment