
## **Caster Installation**

[Retain for future reference.]



## Steps For Assembly

- 1. Install **spring** and **washer** over the caster stem as shown above.
- 2. Insert caster stem into the caster housing.
- 3. Screw on the **stop nut** so that 2 threads of the stem appear above nut (Do not overtighten).
- 4. Before using ladder, be sure all 4 **rubber crutch tips** are installed on the legs of the ladder and are in good condition.
- 5. Understand and follow all usage guidelines and heed all cautions and warnings.



EGA PRODUCTS, INC. Manufacturers of material handling and storage equipment